

TP Series(Basic)

				
Products Series	Model	Offer Repair Spare Part	Delivery Conditions	Picture
TP070	6AV6545-0AA10-0XA0 6AV6545-0AA15-2AX0	LCD Screen, Shell, Touch Glass	New & Replacement	
TP170 A/B	6AV6640-0CA01-0AX0 6AG1545-0BC15-2AX0 6AV6545-0BA15-2AX0 6AV6545-0BB15-2AX0 6AV6545-0BC15-2AX0	LCD Screen, Shell, Touch Glass	New & Replacement	 
TP177 A/B	6AV6640-0CA11-0AX1 6AV6640-0CA11-0AX0 6AV6642-0AA11-0AX1 6AV6642-5BA10-0DU0 6AV6642-0BC01-1AX0 6AG1642-0BC01-4AX1	LCD Screen, Shell, Touch Glass, Membrane Film	New & Replacement	

Repair Parts for SIEMENS HMI & PLC

<p>TP177 A/B</p>	<p>6AV6642-0BA01-1AX1 6AV6642-0BC01-1AX1 6AG1642-0BA01-4AX0 6AV6642-0BA01-1AX0 6AG1642-0BA01-4AX1 6AV6642-0AA11-0AX0 6AV6642-8BA10-0AA0</p>			
<p>TP7</p>	<p>6AV3627-1NK00-2AX0 6AV3627-1QK00-2AX0 6AV3627-1NK00-0AX0 6AV3627-1QK00-0AX0</p>	<p>LCD Screen, Touch Glass, Membrane Film</p>	<p>New & Replacement</p>	
<p>TP27</p>	<p>6AV3627-1NK00-2AX0 6AV3627-1QK00-2AX0 6AV3627-1NK00-0AX0 6AV3627-1QK00-0AX0</p>	<p>LCD Screen, Touch Glass, Membrane Film</p>	<p>New & Replacement</p>	
<p>TP37</p>	<p>6AV3637-1PL00-0AX0</p>	<p>LCD Screen, Touch Glass, Membrane Film</p>	<p>New & Replacement</p>	
<p>TP270</p>	<p>6AV6545-0CC10-0AX0 6AG1545-0CC10-4AX0 6AV6545-8CC10-0AA0</p>	<p>LCD Screen, Shell, Touch Glass, Membrane Film</p>	<p>New & Replacement</p>	






Repair Parts for SIEMENS HMI & PLC

<p>TP277</p>	<p>6AV6643-0AA01-1AX1 6AG1643-0AA01-4AX0 6AV6643-0AA01-1AX0</p>	<p>LCD Screen, Shell, Touch Glass, Membrane Film</p>	<p>New & Replacement</p>	
<h2>TP Series(Comfort)</h2>				
<p>TP700</p>	<p>6AG1124-0GC01-4AX0 6AV2144-8GC10-0AA0 6AV2124-0GC01-0AX0 6AG2124-0GC13-1AX0 6AV2143-6GB00-0AA0 6AV2124-0GC13-0AX0 6AV2124-5GC00-0WF0 6AG1124-0GC13-2AX0</p>	<p>LCD Screen, Touch Glass, Membrane Film</p>	<p>New & Replacement</p>	
<p>TP900</p>	<p>6AG1124-0JC01-4AX0 6AV2144-8JC10-0AA0 6AV2124-0JC01-0AX0</p>	<p>LCD Screen, Touch Glass, Membrane Film</p>	<p>New & Replacement</p>	
<p>TP1000F</p>	<p>6AV2145-6KB20-0AS0</p>	<p>LCD Screen, Touch Glass, Membrane Film</p>	<p>New & Replacement</p>	

Repair Parts for SIEMENS HMI & PLC

<p>TP1200</p>	<p>6AV2124-0MC24-1AX0 6AV2124-0MC24-0AX0 6AV2124-0MC24-0BX0 6AV2124-0MC01-0AX0 6AV2144-8MC10-0AA0 6AG1124-0MC01-4AX0</p>	<p>LCD Screen, Touch Glass, Membrane Film</p>	<p>New & Replacement</p>	
<p>TP1500</p>	<p>6AG1124-0QC02-4AX0 6AV2144-8QC10-0AA0 6AV2124-0QC02-0AX0 6AV2124-0QC02-0AX1 6AV2124-0QC24-0BX0 6AV2124-0QC24-1AX0 6AV2124-0QC13-0AX0 6AV2124-0QC24-0AX0 6AG1647-0AG11-4AX0 6AV6647-0AG11-3AX0</p>	<p>LCD Screen, Touch Glass, Membrane Film</p>	<p>New & Replacement</p>	
<p>TP1900</p>	<p>6AG1124-0UC02-4AX0 6AV2144-8UC10-0AA0 6AV2124-0UC02-0AX0 6AV2124-0UC02-0AX1 6AV2124-0UC24-0BX0 6AV2124-0UC24-1AX0</p>	<p>LCD Screen, Membrane Film, Touch Glass</p>	<p>New & Replacement</p>	




Repair Parts for SIEMENS HMI & PLC

<p>TP1900</p>	<p>6AV2124-0UC24-0AX0</p>			
<p>TP2200</p>	<p>6AG1124-0XC02-4AX0 6AV2124-0XC02-0AX0 6AV2124-0XC24-0AX0 6AV2124-0XC02-0AX1 6AV2124-0XC24-1AX0 6AV2124-0XC24-0BX0</p>	<p>LCD Screen, Membrane Film, Touch Glass</p>	<p>New & Replacement</p>	 
<h2>Simatic Multi Panel</h2>				
<p>MP177</p>	<p>6AV6652-2JD01-2AA0 6AV6652-2JD01-2AA1 6AV6642-6EA10-0UH0 6AG1642-0EA01-4AX0 6AV6642-0EA01-3AX0 6AV6652-2JC01-2AA0</p>	<p>LCD Screen Shell, Membrane Film, Touch Glass</p>	<p>New & Replacement</p>	
<p>MP277</p>	<p>6AV6643-0CB01-1AX0 6AV6643-0CB01-1AX1 6AV6643-0CB01-1AX2 6AV6643-0CB01-1AX5 6AV6643-5CB00-0ND1</p>	<p>LCD Screen Shell, Membrane Keypad, Membrane Film, Touch Glass</p>	<p>New & Replacement</p>	

Repair Parts for SIEMENS HMI & PLC

	<p>6AV6643-5CB10-0HW0</p> <p>6AV6652-3MB01-0AA0</p> <p>6AV6652-3MC01-1AA0</p>			
MP377	<p>6AV6652-4FA01-0AA0</p> <p>6AV6652-4FC01-2AA0</p> <p>6AV6644-0AA01-2AX1</p> <p>6AG1644-0AA01-4AX0</p> <p>6AV6644-0AA01-2AX0</p> <p>6AV6644-5AA10-0HW0</p> <p>6AV6644-5AA10-0BJ0</p> <p>6AV6644-5AA10-0CG0</p>	<p>LCD Screen</p> <p>Shell,</p> <p>Membrane Keypad,</p> <p>Membrane Film,</p> <p>Touch Glass</p>	New & Replacement	 
MP270	<p>6AV6542-0AA15-1AX0</p> <p>6AV6542-0AB15-1AX0</p> <p>6AV6542-0AC15-2AX0</p> <p>6AV6542-0AD15-2AX0</p> <p>6AV6542-0AE15-2AX0</p> <p>6AV6542-0AF15-2AX0</p> <p>6AV6542-0AG10-0AX0</p> <p>6AV6545-0AG10-0AX0</p> <p>6AV6545-0AG10-0NX0</p>	<p>LCD Screen</p> <p>Shell,</p> <p>Membrane Keypad,</p> <p>Membrane Film,</p> <p>Touch Glass</p>	New & Replacement	 

Repair Parts for SIEMENS HMI & PLC

MP370	6AV6545-0DA10-0AX0	LCD Screen	New & Replacement	  
	6AG1545-0DA10-4AX0	Shell,		
	6AV6545-0AD10-0AX0	Membrane Keypad,		
	6AV6542-0AD10-0AX0	Membrane Film,		
	6AV6542-0DA10-0AX0	Touch Glass		




Simatic KP Panel

KP300	6AV6647-0AH11-3AX0 6AG1647-0AH11-2AX0 6AG2647-0AH11-1AX0	LCD Screen Membrane Keypad	New & Replacement	
KP400 Basic	6AV6647-0AJ11-3AX0	LCD Screen Membrane Keypad	New & Replacement	
KP400	6AV2124-1DC01-0AX0 6AG1124-1DC01-4AX0	LCD Screen Membrane Keypad	New & Replacement	
KP700	6AV2124-1GC01-0AX0 6AG1124-1GC01-4AX0	LCD Screen Membrane Keypad	New & Replacement	

Repair Parts for SIEMENS HMI & PLC

KP900	6AV2124-1JC01-0AX0	LCD Screen	New & Replacement	
	6AG1124-1JC01-4AX0	Membrane Keypad		
KP1200	6AV2124-1MC01-0AX0	LCD Screen	New & Replacement	
	6AG1124-1MC01-4AX0	Membrane Keypad		
KP1500	6AV2124-1QC02-0AX1	LCD Screen	New & Replacement	
	6AG1124-1QC02-4AX0	Membrane Keypad		
	6AV2124-1QC02-0AX0			
	6AG1124-1QC02-4AX1			


Simatic C7 Panel

C7-613	6ES7613-1CA00-0AE3	LCD Screen	New & Replacement	  
	6ES7613-1CA01-0AE3	Shell,		
	6ES7613-1CA02-0AE3	Membrane Keypad		
	6ES7613-1SB02-0AC0			
	6ES7613-1SB02-1AC0			
	6AG1613-1CA02-4AE3			
	6AG1613-1SB01-4AC0			
	6AG1613-1SB02-4AC0			
	6AG1913-1CA01-1AE3			
	6ES7613-0CA00-7AA0			

Repair Parts for SIEMENS HMI & PLC

	6ES7613-1SB02			
C7-621	6ES7621-1AD00-0AE3 6ES7621-1AD01-0AE3 6ES7621-1SE00-0AE3 6ES7621-6BD00-0AE3 6ES7621-6BD01-0AE3 6ES7621-6BD02-0AE3 6ES7621-6SE00-0AE3	Shell, Membrane Keypad	New & Replacement	
C7-623	6ES7623-1AE00-0AE3 6ES7623-1AE01-0AE3 6ES7623-1CE01-0AE3 6ES7623-1DE01-0AE3 6ES7623-1CE00-0AE3 6ES7623-1SB01-0AC0 0005-4050-340	Shell, Membrane Keypad	New & Replacement	
C7-624	6ES7624-1AE00-0AE3 6ES7624-1AE01-0AE3 6ES7624-1DE01-0AE3	Membrane Keypad	New & Replacement	
C7-626	6ES7626-1AG00-0AE3	Shell,	New & Replacement	


Repair Parts for SIEMENS HMI & PLC

	6ES7626-1AG01-0AE3 6ES7626-1AG02-0AE3 6ES7626-1CG00-0AE3 6ES7626-1CG01-0AE3 6ES7626-1CG02-0AE3 6ES7626-1DG02-0AE3 6ES7626-1DG03-0AE3 6ES7626-1DG04-0AE3 6ES7626-2AG00-0AE3 6ES7626-2AG01-0AE3 6ES7626-2AG02-0AE3 6ES7626-2CG01-0AE3 6ES7626-2DG02-0AE3 6ES7626-2DG03-0AE3 6ES7626-2DG04-0AE3 6ES7626-2CG00-0AE3 6ES7626-1AG01-0AE3 0005-4050-310 0005-4050-360	Membrane Keypad		
C7-633	6ES7633-1DF00-0AE3 6ES7633-1DF01-0AE3 6ES7633-1DF02-0AE3 6ES7633-2BF00-0AE3	Shell, Membrane Keypad	New & Replacement	




Repair Parts for SIEMENS HMI & PLC

	<p>6ES7633-2BF01-0AE3</p> <p>6ES7633-2BF02-0AE3</p> <p>6ES7633-2BJ01-0AE3</p> <p>6ES7633-2BJ02-0AE3</p> <p>6ES7633-2SE00-0AE3</p> <p>6ES7633-2DF00-0AE3</p>			 
C7-634	<p>6ES7634-1DF00-0AE3</p> <p>6ES7634-1DF01-0AE3</p> <p>6ES7634-1DF02-0AE3</p> <p>6ES7634-2BF00-0AE3</p> <p>6ES7634-2BF01-0AE3</p> <p>6ES7634-2BF02-0AE3</p> <p>6ES7634-2DF00-0AE3</p>	<p>Shell,</p> <p>Membrane Keypad</p>	New & Replacement	 
C7-635(Key)	<p>6ES7635-2EC00-0AE3</p> <p>6ES7635-2EC01-0AE3</p> <p>6ES7635-2EC02-0AE3</p> <p>6ES7635-2SE00-0AE3</p> <p>6AG1635-2EC02-4AE3</p> <p>6AG1635-2SB02-4AC0</p> <p>6AG1935-2SB00-4AC0</p>	<p>LCD Screen,</p> <p>Shell,</p> <p>Membrane Keypad</p>	New & Replacement	 
C7-635(Touch)	<p>6ES7635-2EB00-0AE3</p> <p>6ES7635-2EB01-0AE3</p>		New & Replacement	



Repair Parts for SIEMENS HMI & PLC

	6ES7635-2EB02-0AE3 6ES7635-3SE00-0AE3	LCD Screen, Touch Glass Shell, Membrane Keypad		
C7-636	6EA7636-2EB00-0AE3 6ES7636-2EC00-0AE3 6ES7636-2EB00-0AE3 6ES7636-3SA01-0AB0	LCD Screen, Protective Glass, Membrane Keypad	New & Replacement	



Simatic OP Panel

OP3	6AV3503-1DB10	Shell, Membrane Keypad	New & Replacement	
OP5	6AV3505-1FB00 6AV3505-1FB01 6AV3505-1FB12	Membrane Keypad	New & Replacement	
OP7	6AG1607-1JC20-4AX1 6AG1607-1JC20-4AX2 6AG1607-1JC30-4AX1 6AG1607-1JC30-4AX2 6AV3607-1JC00-0AX0 6AV3607-1JC00-0AX1	Shell, Membrane Keypad	New & Replacement	


Repair Parts for SIEMENS HMI & PLC

	<p>6AV3607-1JC00-0AX2</p> <p>6AV3607-1JC20-0AX0</p> <p>6AV3607-1JC20-0AX1</p> <p>6AV3607-1JC20-0AX2</p> <p>6AV3607-1JC30-0AX0</p> <p>6AV3607-1JC30-0AX1</p> <p>6AV3607-1JC30-0AX2</p> <p>6AV3607-5AA00-0AC0</p> <p>6AV3607-5BA00-0AK0</p> <p>6AV3607-5BB00-0AE0</p> <p>6AV3607-5BB00-0AF0</p> <p>6AV3607-5BB00-0AG0</p> <p>6AV3607-5BB00-0AH0</p> <p>6AV3607-5BB00-0AL0</p> <p>6AV3607-5CA00-0AD0</p>			
<p>OP73</p>	<p>6AV6641-0AA11-0AX0</p> <p>6AG1641-0AA11-4AX0</p> <p>6AV6640-0BA11-0AX0</p> <p>6AV6651-1AA01-0AA0</p> <p>6AV6650-0BA01-0AA0</p>	<p>Shell, Membrane Keypad</p>	<p>New & Replacement</p>	



Repair Parts for SIEMENS HMI & PLC

<p>OP77</p>	<p>6AV6641-0CA01-0AX0</p> <p>6AV6641-0CA01-0AX1</p> <p>6AV6641-0BA11-0AX1</p> <p>6AV6641-0BA11-0AX0</p> <p>6AG1641-0CA01-4AX1</p> <p>6AG1641-0CA01-4AX0</p> <p>6AV6651-1CA01-0AA0</p> <p>6AV6651-1BA01-0AA0</p>	<p>Shell,</p> <p>Membrane Keypad</p>	<p>New & Replacement</p>	
<p>OP15</p>	<p>6AV3515-1MA20-1AA0</p> <p>6AV3515-1MA22-1AA0</p> <p>6AV3515-1EB30-1AA0</p> <p>6AV3515-1EB32-1AA0</p> <p>6AV3515-1MA30-1AA0</p> <p>6AV3515-1EB10-1AA0</p> <p>6AV3515-1EB00</p> <p>6AV3515-1EB00-Z</p> <p>6AV3515-1EB01</p> <p>6AV3515-1EB30</p> <p>6AV3515-1EB32</p> <p>6AV3515-1EK30</p> <p>6AV3515-1EK30-1AA0</p> <p>6AV3515-1EK32</p> <p>6AV3515-1EK32-1AA0</p>	<p>Membrane Keypad</p>	<p>New & Replacement</p>	



Repair Parts for SIEMENS HMI & PLC

	<p>6AV3515-1MA00</p> <p>6AV3515-1MA00-Z</p> <p>6AV3515-1MA01</p> <p>6AV3515-1MA20</p> <p>6AV3515-1MA22</p> <p>6AV3515-1MA30</p> <p>6AV3515-1MA32</p>			
<p>OP17</p>	<p>6AV3617-4EB12-0AA0</p> <p>6AV3617-4EB42-0AA0</p> <p>6AV3617-1JC00-0AX2</p> <p>6AV3617-1JC20-0AX2</p> <p>6AV3617-1JC30-0AX2</p> <p>6AV3617-1JC30-0AX1</p> <p>6AV3617-1JC00-0AX1</p> <p>6AV3617-1JC20-0AX1</p> <p>6AV3617-1JC30-0AX0</p> <p>6AV3617-4EB42-0AL0</p> <p>6AV3617-4EB42-1AA0</p> <p>6AV3617-4FB42-0AL0</p> <p>6AV3617-5BA00-0BC0</p> <p>6AV3617-5BB00-0AB0</p> <p>6AV3617-5BB00-0AB1</p> <p>6AV3617-5BB00-0AJ0</p>	<p>Shell,</p> <p>Membrane Keypad</p>	<p>New & Replacement</p>	




Repair Parts for SIEMENS HMI & PLC

	<p>6AV3617-5BB00-0BD0</p> <p>6AV3617-5BB00-OBEO</p> <p>6AV3617-5CA00-0AD0</p> <p>6AV3617-5BB00-0AE0</p>			
OP25	<p>6AV3525-4EA01-ZA03</p> <p>6AV3525-1TA41-0BX0</p> <p>6AV3525-7EA01-0AX0</p> <p>6AV3525-4EA01-0AX0-ZA03</p> <p>6AV3525-1EA01-0AX0</p> <p>6AV3525-1EA41-0AX0</p> <p>6AV3525-1EA41-0AX1</p>	<p>LCD Screen,</p> <p>Protective Glass,</p> <p>Membrane Keypad</p>	New & Replacement	
OP27	<p>6AV3627-1LK00-0AX0</p> <p>6AV3627-7JK00-0AX0</p> <p>6AV3627-1JK00-1AX0</p> <p>6AV3627-7LK00-0BD0</p> <p>6AV3627-5AB00-0AC0</p> <p>6AV3627-5AB00-0AD0</p> <p>6AV3627-5BB00-0AE0</p> <p>6AV3627-6JK00-0BF0</p> <p>6AV3627-6LK00-0AA0</p> <p>6AV3627-1SK00-0AX0</p> <p>6AV3627-1JK00-0AX0</p>	<p>LCD Screen,</p> <p>Protective Glass,</p> <p>Membrane Keypad</p>	New & Replacement	

Repair Parts for SIEMENS HMI & PLC

	6AV3627-1LK00-1AX0 6AV3627-5AB00-0BF0			
OP35	6AV3535-1FA01-0AX0 6AV3535-1FA01-1AX0 6AV3535-1FA01-1AX1 6AV3535-1FA41-0BX0 6AV3535-1FA41-0BX1 6AV3535-1TA01-0AX0 6AV3535-1TA41-0BX0 6AV3535-1TA41-0BX1	LCD Screen, Protective Glass, Membrane Keypad	New & Replacement	
OP37	6AV3637-1LL00-0CX0 6AV3637-1LL00-0FX0 6AV3637-1LL00-0GX0 6AV3637-1ML00-0GX0 6AV3637-5AB00-0AC0 6AV3637-1LL00-0XB0 6AV3637-1LL00-0AX0 6AV3637-1LL00-0AX1 6AV3637-1LL00-0BX0 6AV3637-1LL00-0FX1 6AV3637-1ML00-0BX0 6AV3637-1ML00-0CX0 6AV3637-1ML00-0FX0	LCD Screen, Protective Glass, Membrane Keypad	New & Replacement	



Repair Parts for SIEMENS HMI & PLC

<p>OP37-OEM</p>	<p>6AV3637-6AA26-0AA0</p> <p>6AV3637-6AB55-0AC0</p> <p>6AV3637-6AB55-0AC1</p> <p>6AV3637-6AB56-0AH0</p> <p>6AV3637-6BC44-0AD0</p> <p>6AV3637-6BC54-0AD0</p> <p>6AV3637-7AB06-0AE0</p> <p>6AV3637-7AB06-1AE0</p> <p>6AV3637-7AB16-0AE0</p> <p>6AV3637-7AB16-0AG0</p> <p>6AV3637-7AB16-0AG1</p> <p>6AV3637-7AB16-0AM0</p> <p>6AV3637-7AB26-0AA0</p> <p>6AV3637-7AB26-0AB0</p> <p>6AV3637-7AB26-1AA0</p> <p>6AV3637-7AB16-1AM0</p> <p>6AV3637-7AB26-0AN0</p>	<p>LCD Screen,</p> <p>Protective Glass,</p> <p>Membrane Keypad</p>	<p>New & Replacement</p>	
<p>OP45</p>	<p>6AV3545-1VC12-3FX0</p> <p>6AV3545-1VB12-3FX0</p> <p>6AV3545-1VA01-2FX0</p>	<p>LCD Screen,</p> <p>Protective Glass,</p> <p>Membrane Keypad</p>	<p>New & Replacement</p>	
<p>OP47</p>	<p>6AV6647-xxxxx</p> <p>Series</p>	<p>LCD Screen,</p> <p>Membrane Keypad</p>	<p>New & Replacement</p>	


Repair Parts for SIEMENS HMI & PLC

<p>OP170</p>	<p>6AV6542-0BB15-2AX0</p>	<p>LCD Screen, Shell, Protective Glass, Membrane Keypad</p>	<p>New & Replacement</p>	
<p>OP177</p>	<p>6AG1642-0BC01-4AX0 6AG1642-0DA01-4AX0 6AG1642-0DA01-4AX1 6AG1642-0DC01-4AX0 6AG1642-0DC01-4AX1 6AV6551-2HA01-1AA0 6AV6642-0DA01-1AX0 6AV6642-0DA01-1AX1 6AV6642-0DC01-1AX0 6AV6642-0DC01-1AX1 6AV6642-5DC10-1AC0 0005-4050-710 0005-4050-810 0005-4050-818 0005-4050-950</p>	<p>LCD Screen, Shell, Touch Glass Membrane Keypad</p>	<p>New & Replacement</p>	  
<p>OP270 6"</p>	<p>6AV6542-0CA10-0AX1 6AV6542-0CA10-0AX0</p>	<p>LCD Screen, Protective Glass, Membrane Keypad</p>	<p>New & Replacement</p>	

Repair Parts for SIEMENS HMI & PLC

<p>OP270 10"</p>	<p>6AV6542-0CC10-0AX0 6AV6542-0CC15-0AX0</p>	<p>LCD Screen, Protective Glass, Membrane Keypad</p>	<p>New & Replacement</p>	
<p>OP277 6"</p>	<p>6AV6643-0BA01-1AX0 6AV6643-7BA00-0CJ0 6AV6643-7BA00-0CJ1 6AV6643-0BA01-1AX1 6AG1643-0BA01-4AX1</p>	<p>LCD Screen, Shell, Touch Glass Membrane Keypad</p>	<p>New & Replacement</p>	

Simatic KTP Panel

<p>KTP400</p>	<p>6AV6647-0AA11-3AX0 6AV6647-0AK11-3AX0 6AV2124-2DC01-0AX0 6AG1124-2DC01-4AX0 6AG1123-2DB03-2AX0 6AV2123-2DB03-0AX0 6AG1647-0AA11-2AX0 6AV2125-2DB23-0AX0</p>	<p>LCD Screen, Shell, Touch Glass Membrane Keypad</p>		
----------------------	---	--	--	---





Repair Parts for SIEMENS HMI & PLC

				
KTP600	<p>6AV6647-0AB11-3AX0</p> <p>6AV6647-0AC11-3AX0</p> <p>6AV6647-0AD11-3AX0</p> <p>6AG1647-0AD11-2AX0</p>	<p>LCD Screen,</p> <p>Shell,</p> <p>Touch Glass</p> <p>Membrane Keypad</p>	New & Replacement	 
KTP700	<p>6AG1123-2GA03-2AX0</p> <p>6AG1123-2GB03-2AX0</p> <p>6AV2123-2GA03-0AX0</p> <p>6AV2123-2GB03-0AX0</p>	<p>LCD Screen,</p> <p>Shell,</p> <p>Touch Glass</p> <p>Membrane Keypad,</p> <p>Motherboard</p>	New & Replacement	  




Repair Parts for SIEMENS HMI & PLC

				  
KTP700F	6AV2125-2GB03-0AX0 6AV2125-2GB23-0AX0	LCD Screen, Touch Glass Membrane Film	New & Replacement	
KTP900	6AG1123-2JB03-2AX0 6AV2123-2JB03-0AX0	LCD Screen, Touch Glass Membrane Keypad	New & Replacement	
KTP900F	6AV2125-2JB03-0AX0 6AV2125-2JB23-0AX0	LCD Screen, Touch Glass Membrane Film	New & Replacement	



Repair Parts for SIEMENS HMI & PLC

<p>KTP1000</p>	<p>6AV6647-0AE11-3AX0 6AV6647-0AF11-3AX0 6AG1647-0AE11-4AX0 6AG1647-0AF11-4AX0</p>	<p>LCD Screen, Shell, Touch Glass Membrane Keypad</p>	<p>New & Replacement</p>	
<p>KTP1200</p>	<p>6AG1123-2MA03-2AX0 6AG1123-2MB03-2AX0 6AV2123-2MA03-0AX0 6AV2123-2MB03-0AX0</p>	<p>LCD Screen, Touch Glass Membrane Keypad</p>	<p>New & Replacement</p>	
<h3>Simatic Mobile Panel</h3>				
<p>Mobile Panel 170</p>	<p>6AV6545-4BA16-0CX0 6AV6545-4BB16-0CX0 6AV6545-4BC16-0CX0</p>	<p>LCD Screen, Shell, Touch Glass Membrane Keypad</p>	<p>New & Replacement</p>	
<p>Mobile Panel 177</p>	<p>6AV6645-0AA01-0AX0 6AV6645-0AB01-0AX0 6AV6645-0AC01-0AX0</p>	<p>LCD Screen, Shell, Touch Glass</p>	<p>New & Replacement</p>	


Repair Parts for SIEMENS HMI & PLC

	<p>6AV6645-0BA01-0AX0</p> <p>6AV6645-0BB01-0AX0</p> <p>6AV6645-0BC01-0AX0</p>	<p>Membrane Keypad</p>		
<p>Mobile Panel 277</p>	<p>6AV6645-0CA01-0AX0</p> <p>6AV6645-0CB01-0AX0</p> <p>6AV6645-0CC01-0AX0</p> <p>6AV6645-0DD01-0AX0</p> <p>6AV6645-0DD01-0AX1</p> <p>6AV6645-0DE01-0AX0</p> <p>6AV6645-0FD01-0AX0</p> <p>6AV6645-0DB01-0AX0</p> <p>6AV6645-0DC01-0AX0</p> <p>6AV6645-0EB01-0AX1</p> <p>6AV6645-0EC01-0AX1</p> <p>6AV6645-0EF01-0AX1</p> <p>6AV6645-0FD01-0AX1</p> <p>6AV6645-0FE01-0AX0</p> <p>6AV2124-0XC24-0AX0</p> <p>6AV6645-0FE01-0AX1</p> <p>6AV6645-0GB01-0AX0</p> <p>6AV6645-0GC01-0AX0</p> <p>6AV6645-0GC01-0AX1</p>	<p>LCD Screen,</p> <p>Shell,</p> <p>Touch Glass</p> <p>Membrane Keypad</p>	<p>New & Replacement</p>	 

Repair Parts for SIEMENS HMI & PLC

	6AV6645-0GF01-0AX1 6AV6645-0DD02-0AX1 6AV6645-0DE02-0AX1 6AV6645-0EC02-0AX1 6AV6645-0EB02-0AX1 6AV6645-0EF02-0AX1 6AV6651-5GA01-0AA1 6AV6651-5HA01-0AA1			
<h3>Simatic TD Text Panel</h3>				
TD17	6AV3017-1NE30-0AX1 6AV3017-1NE30-0AX0 6AV3017-1NE30	Membrane Keypad	New & Replacement	
TD200C	6AG1272-1AA10-2YA1 6AG1272-0AA30-2YA0 6ES7272-1AA10-0YA1 6ES7272-1AF00-7AA0 6ES7272-1AA10-0YA0	Shell, Membrane Keypad	New & Replacement	

Repair Parts for SIEMENS HMI & PLC

<p>TD390</p>	<p>6ES5390-0UA11</p>	<p>Membrane Keypad</p>	<p>New & Replacement</p>	
<p>TD400C</p>	<p>6AV6671-0AP00-0AX0 6AV6640-0AA00-0AX1 6AG1640-0AA00-2AX1</p>	<p>Shell, Membrane Keypad</p>	<p>New & Replacement</p>	
<h2>Simatic Smart Panel</h2>				
<p>Smart 700</p>	<p>6AV6648-0CC11-3AX0 6AV6648-0BC11-3AX0 6AV6648-0AC11-3AX0</p>	<p>LCD Screen, Touch Glass, Membrane Film</p>	<p>New & Replacement</p>	 
<p>Smart 1000</p>	<p>6AV6648-0CE11-3AX0 6AV6648-0BE11-3AX0 6AV6648-0AE11-3AX0</p>	<p>LCD Screen, Touch Glass, Membrane Film</p>	<p>New & Replacement</p>	 

Repair Parts for SIEMENS HMI & PLC

Please go the official website of SEAWENS to find more details, photos and instructions of all the products !

Seawens Technology Co., Limited.

YuHui Electronic Commerce co.,Ltd

Add: Daya Bay West District Street, No. 333 Shihua Avenue West, Huizhou City, Guangdong Province, China

PC: 516000

Web: <https://www.seawens.com>

Phone: +86-185 6588 9964

Shop: <https://www.ia-mall.com>

E-mail: sales@seawens.com